


Installation guide

Solenoid valve


Type EV224B

032R9276


032R9276




1




2




3



4



5



6

